

# TECH TIP


## TUS 025 – PHOTO FRAME TEMPLATES CD

### Directions For Use:

Each template design is saved in a Corel Version 10 file format, and each theme or occasion is available in all of the 4 standard photo size Alder Photo frames: 3½" x 5" (WTH 020), 4" x 6" (WTH 021), 5" x 7" (WTH 031) and 8" x 10" (WTH 022). Each design is given to you in both a horizontally and vertically layout format.

Once you have opened a template you will notice that it has an outline of red, and in certain cases will contain blue boxes. The red outline designates the area the product will take up in your engraver, while the blue box indicates the area to include your personalized text and in some cases a graphic, such as a logo. Make sure to include your text or graphic within this blue box. If you engrave outside the blue lines you will be engraving in an area that is not meant to be engraved in. Templates that do not contain blue boxes just means nothing needs to be added to that particular design.

If you need to make changes to a layer, make sure that layer is unlocked. Simply click the "Tools" button on the tool bar and drag down to "Object Manager". Once you have opened Object Manager you will notice the icon "Page 1". Included beneath Page 1 are the icons Layer 1, Layer 2, and so on. Each layer will be accompanied with an icon of an eye, a printer, and a pen. The eye makes the layer viewable, the printer makes the layer printable, and the pen makes the layer editable. Click on the pen icon so that it no longer has a red circle over it. Now you will be able to make changes to that layer.




### Printing To Your Laser:

Some of the designs contain top bleeds. In order to print these properly with some brands of laser printers you will need to use "Manual focus" when setting up your printer properties. Those designs without a top bleed can be set to "Auto focus".

After you have chosen the frame template to be printed, ALWAYS conduct a "Print Preview" to make sure all the desired items that you want to be engraved are showing.

Once the objects are correctly chosen "Print" the job over to your laser engraver. Now you are ready to engrave your product.



24410 North 20th Drive, Phoenix, AZ 85085 U.S.A.

Tel: 1-800-733-7705 • Fax: 623-879-5149 • Email: order1@laserbits.com • Website: www.laserbits.com

COPYRIGHT © LASERBITS, INC.


# TECH TIP

## More Info About the Templates:

Some of the templates come with text or graphics that can replace some of the items already in the template frame design.


### “Cat” Template

This template comes with extra replacement text. Select the replacement text and drag over into the blue box. Moving the unwanted text out to the side, outside the printable 24 x 12 area.




### “Dog” Template

This template comes with different dog breeds that can replacement the dog already there. Select the breed you want and drag over into the blue box which contains the “Retriever” head and move the “Retriever” out, off the page.



### “Dad” Template

This template comes with an extra replacement figure. You can either replace the figure already in the printable area or you can add the extra figure next to the one already there. See example.



24410 North 20th Drive, Phoenix, AZ 85085 U.S.A.

Tel: 1-800-733-7705 • Fax: 623-879-5149 • Email: order1@laserbits.com • Website: www.laserbits.com

COPYRIGHT © LASERBITS, INC.